





AALBERTS DISPENSE TECHNOLOGIES

REPLACING A BUTTON CAP

Step by step image instruction on replacing a bar gun button cap.

Presentation For Field Technicians





REPLACING A BUTTON CAP



- What you need
 - Bar Gun
 - Replacement Button Cap
 - Flat head screw driver
- Place flat head screw driver under lip of button cap
- Leverage the end of the screw driver upwards against the bottom of the button cap to pop it off and remove it
- Tip: place your finger over the top of the button to keep it from flying off









REPLACING A BUTTON CAP

- Align the replacement button on the actuator
 - Ensure the button reads the same direction as the other buttons
- Press down firmly till button is flush with button plate
 - You will hear/feel it "snap" into place
- You have completed replacing the button cap





